


Removal

1 Remove instrument cluster (54–250).

2 Pull off electrical connection.

3 Unscrew the 4 fastening screws (1).


4 Remove time clock.



154-23199

Installation

5 For installation proceed vice versa.



154-14180